The GSM-17J-3G Modem Kit: Cinterion ,EHS6T

This kit enables your SMS-enabled OPLC to communicate via cellular networks. The kit, GSM-17J Modem Kit, contains a Cinterion EHS6T GSM modem and related hardware. The modem can communicate via GSM, GPRS + TCP/IP at 850/900/1800/1900 MHz.

Connection

The figure below shows you how to assemble the different elements of the Cinterion EHS6T GSM modem, and how to connect the modem to an OPLC.



Component Identification			
#	Description	Notes	
1	Communication cable, controller to modem	Vision, Samba, Unistream, M90/91 series: This is the RS232 programming cable for the controller. Jazz Jazz does not comprise an embedded communication port. Addon ports are available by separate order. Use the communication cable supplied with the Add-on port	
2	9 pin male adapter p/n MJ10-22-CS76		
3	LED		
4	Power supply cable		
5	End of power supply cable	Orange wire + striped orange & white wire—positive, blue wire—negative.	
6	SIM Slot		
7	GSM antenna		
8	GSM antenna connector	Located on modem	

SIM Slot

The SIM-with the circuit side facing upwardsis inserted by gently pushing it into the SIM card holder until it snaps hold.


The SIM can be removed from the card holder by using a flat object such as screwdriver to carefully press the inserted SIM until it snaps out again.



Modem RS232 port pin-out

D-type 9 pin female connector:

Pin	Description	Direction
1	DCD (Data Carrier Detect)	0
2	RxD (Receive Data)	0
3	TxD (Transmit Data)	I
4	DTR (Data Terminal Ready)	I
5	GND (Signal Ground)	-
6	DSR (Data Set Ready)	0
7	RTS (Request to Send)	I
8	CTS (Clear To Send)	0
9	RING (Ring Indicator)	0





LED: Status Indication

EHS6T has two LEDs indicating the operation status through the device casing:

A green LED indicates whether the modem is correctly powered and ready to operate.

A yellow LED indicates the various operation states.(User configuration depend)

Technical Specifications

Modem

Power voltage range 8 - 30VDC

Status indication Green/Yellow LED
SIM card 3V and 1.8V SIM card
GSM frequency 850/900/1800/1900 MHz

Weight 130g (4.58 oz.)

Dimensions 115 x 86 x 26mm (4.52" x 3.38" x 1.02")

Operational temperature $-30 \text{ to } 65 \,^{\circ}\text{C} \ (-22 \text{ to } 149 \,^{\circ}\text{F})$ Storage temperature $-40 \text{ to } 90 \,^{\circ}\text{C} \ (-40 \text{ to } 194 \,^{\circ}\text{F})$

Antenna connector type SMA female

Antenna

Antenna frequency Quad band GSM:850/900/1800/1900/2100 MHz

Unitronics product sold hereunder can be used with certain products of other manufacturers at the user's sole responsibility.

The information provided is subject to change without notice.

Modem initialization*

- Preparing the modem as described below initializes it so that it is compatible with Unitronics PLCs.
- Connect the modem to a PC, using a cable comprising the full RS232 pinout, either supplied in the modem kit or supplied by the modem manufacturer.


Note that using a cable that does not comprise the full RS232 pinout will cause the process to fail.

Prepare the PLC modem:

- 3. Open VisiLogic/U90Ladder.
- 4. Open Connection>Modem Services, and select the modem type. If required, you can edit other parameters: Com Port, Baud Rate, Time Out, and Time-Out Reply: use the drop down boxes. If SIM has PIN code: click to enter the number.
- 5. Click the Prepare PLC-side Modem button; dialog box opens.
- When all parameters are set, click the Init Modem button; the PC establishes communication with the modem and initializes it.
- 7. Now you can connect the modem to the PLC using the 9 Pin connector MJ10-22-CS76 via cable 4 wires.

*It is not required to prepare the modem while using Unistream.





Note that the EHS6T model firmware should be 3.001.

The information in this document reflects products at the date of printing. Unitronics reserves the right, subject to all applicable laws, at any time, at its sole discretion, and without notice, to discontinue or change the features, designs, materials and other specifications of its products, and to either permanently or temporarily withdraw any of the forgoing from the market.

All information in this document is provided "as is" without warranty of any kind, either expressed or implied, including but not limited to any implied warranties of merchantability, fitness for a particular purpose, or non-infringement. Unitronics assumes no responsibility for errors or omissions in the information presented in this document. In no event shall Unitronics be liable for any special, incidental, indirect or consequential damages of any kind, or any damages whatsoever arising out of or in connection with the use or performance of this information.

The tradenames, trademarks, logos and service marks presented in this document, including their design, are the property of Unitronics (1989) (R"G) Ltd. or other third parties and you are not permitted to use them without the prior written consent of Unitronics or such third party as may own them.

DOC01003-A2 08/15